

INSTALLATION, CONT.

3. Install check and gate valves in discharge line; check valve (if used) between pump and gate valve.

OPERATION

Pre-Start — Before initial start of the pump, check as follows:

1. The rotation must be checked upon installation. Close, then break the contacts quickly and observe the rotation of the exposed portion of the rotating parts. Rotation must agree with the rotation arrow on the motor. For all pumps, the standard rotation is counterclockwise when viewed from the suction end. Motor wiring is easily changed in the field. Observe the wiring diagram on the inside of the terminal box cover, or on the motor nameplate.
2. Check voltage, phase and frequency of line circuit with motor nameplate.
3. Check suction and discharge piping and pressure gauges for proper operation.
4. Assure that pump is full of liquid (primed).

Priming — If pump is installed with a positive head on the suction, prime by opening suction valve and allowing liquid to enter the casing, at the same time venting all air out of the top of the casing.

If pump is installed with a suction lift, priming must be done by other methods, such as foot valves, ejectors, or by manually filling casing and suction line.

CAUTION - DO NOT RUN PUMP DRY HOPING IT WILL SELF-PRIME. Serious damage may result if started dry.

Starting — Proceed as follows to start pump:

1. Close drain valves and valve in discharge line.
2. Open fully all valves in the suction line.
3. Prime the pump. If pump does not prime properly, or loses prime during start-up, shut down and correct condition before repeating procedure.
4. For pumps moving high temperature liquids, open warm-up valve to circulate liquid for preheating. Close valve after pump has warmed up.
5. Start the motor (pump).
6. When pump is operating at full speed, open discharge valve slowly.

Running — Periodically inspect pump while running, but especially after first start and following repair.

1. Check pump and piping for leaks. Repair immediately.
2. Record pressure gauge readings for future reference.
3. Record voltage, amperage per phase, and kW (if an indicating wattmeter is available).
4. Adjust pump output capacity with discharge valve. DO NOT throttle suction line.

Freezing Protection — Protect pumps shut down during freezing conditions by one of the following methods:

1. Drain pump; remove all liquid from the casing.
2. Keep fluid moving in pump and insulate or heat the pump to prevent freezing. If heated, do not let temperature go above 100 to 150 degrees F.
3. Fill pump completely with antifreeze solution.

MAINTENANCE

Cleaning — Remove oil, dust, dirt, water, chemicals from exterior of motor and pump. Keep motor air inlet and outlet open. Blow out interior of open motors with clean compressed air at low pressure. Regularly drain moisture from TEFC motors.

Temperature — Total temperature, not the rise, is the measure of safe operation for a motor. If temperature by thermometer exceeds limits for insulation class, investigate and change operating conditions.

Labeled Motors — It is imperative for repair of a motor with Underwriters' Laboratories label that original clearances be held; that all plugs, screws, other hardware be fastened securely, and that parts replacements be exact duplicates or approved equals. Violation of any of the above invalidates Underwriters' label.

Lubrication — Pumps should require no maintenance, other than the motor bearings, according to the following instructions:

DOUBLE SHIELDED. When double shielded prelubricated bearings are furnished, no lubrication is required for the life of the bearings. Inspect bearings periodically to determine the condition of the grease and replace the bearings if necessary.

SINGLE SHIELDED W/GREASE FITTING PROVISIONS. When single shielded bearings are furnished, periodic inspection, cleaning and relubrication is required. See motor manufacturer's specific instructions for lubrication.

MECHANICAL SEAL REPLACEMENT

JM FRAME MOTOR

A.) Disassembly:

1. Turn off power.
2. Close suction and discharge valves.
3. Drain pump.
4. Remove bolts holding base to foundation.
5. Remove casing bolts.
6. Remove motor and rotating element from casing, leaving casing and piping undisturbed.
7. Insert a screwdriver in one of the impeller waterway passages and back off the impeller retaining assembly with a socket wrench, as shown in Figure 1.





Figure 1

8. Remove impeller from shaft, being careful not to lose the impeller key, spring and seal retainer. If impeller is difficult to remove, it may be necessary to use a bearing puller to pull off impeller.
9. Pry off rotating member of mechanical seal from sleeve by using two (2) screwdrivers. (Figure 2)



10. Remove bolts holding adapter to motor and take off adapter.
11. Place adapter on a flat surface with case rabbet facing down, and push out stationary part of mechanical seal.
12. Inspect the shaft sleeve, shaft O-ring and flinger. If damaged or worn, remove and replace with a new one.

B.) Reassembly:

CAUTION: The mechanical seal is a precision product and should be handled accordingly. Use care when handling the lapped running surfaces of the mechanical seal to ensure they remain clean and free of chips or scratches.

1. Clean gasket and flange faces, seal seat cavity, shaft sleeve, and motor shaft.
2. Position the stationary seat with the silver dot down (away from you) and the lapped face (shiny side) facing you. Lubricate the seal seat cavity of the adapter and the rubber cup or O-ring of seal seat with the lubricating fluid that comes with the mechanical seal or repair kit. Press the stationary seat in seal seat cavity of the adapter squarely and evenly using a arbor press (if possible) and the cardboard disc supplied with the seal. Be certain that the lapped face (shiny side) is facing you.
3. Install the flinger on the motor shaft until it bottoms on the motor shaft.
4. Slide the shaft O-ring on the motor shaft until it is tight against the flinger. Make sure that the shaft O-ring does not get damaged during this procedure.
5. Position shaft sleeve chamfer towards motor and slide on motor shaft.
6. With motor preferably in vertical position, remount the adapter on motor, making sure the motor shaft does not dislocate or chip the stationary seat of the seal.
7. Apply the lubricating fluid that comes with the mechanical seal or repair kit to the shaft sleeve and the rubber bellows of the rotary seal. Slide the seal head on the sleeve; press the rubber drive band on the rotary head until the lapped face on the head seats firmly against the lapped face of the

stationary seat. Do not chip or scratch faces during installation. Take extra care to make sure the lapped faces are clean. Install seal spring on seal head and retainer on spring.

8. Place key in key seat. Line up keyway in impeller with key on motor shaft, and slide impeller on motor shaft. Be certain that the key is positioned in the keyway of the motor and impeller. Slightly compress seal spring with impeller and hold impeller while installing impeller retaining assembly in motor shaft.
9. Insert a screwdriver in a waterway passage of the impeller holding it against rotation and tighten the retaining assembly as discussed in paragraph 7 of disassembly instructions. The impeller will compress the seal spring to the proper length assuring the correct pressure on the lapped surfaces.
10. Remove any burrs caused by screwdriver on the vane of impeller in waterway passage.
11. Slide motor and rotating element in casing. Be sure that any damaged O-ring or gasket is replaced.
12. Tighten casing bolts alternately and evenly.
13. Replace hold-down bolts.
14. Check for free rotation after assembly is completed.
15. Seal all drain openings using pipe sealant on threads.
16. Reprime before starting. Do not start until pump is completely filled with water.

MECHANICAL SEAL REPLACEMENT

C56 FRAME MOTOR

A.) Disassembly:

1. Refer to "JM FRAME" Disassembly, Notes 1-11.
12. Inspect the stub shaft. If damaged or worn, replace with a new one; removal:
 - A.) Drive pin from stub shaft and remove pin.
 - B.) Loosen set screws
 - C.) Remove stub shaft from motor shaft.

Assembly:

For motors with drilled hole:

- A.) Slide stub shaft on motor shaft. Line up set screws in stub shaft with motor keyway, and drilled hole in stub shaft with drilled hole in motor shaft.
- B.) Tighten set screws
- C.) Insert #12 drill in pilot hole of stub and motor shaft. Drill out opposite side of stub shaft.
- D.) Install pin

For motors without a drilled hole in the motor shaft:

- A.) Slide stub shaft on motor shaft. Line up set screws in stub shaft with keyway in motor shaft.
- B.) Position stub 3 3/32" from Motor C face. See Figure 1.
- C.) Tighten set screws
- D.) Insert #12 drill in stub shaft pilot hole and drill completely through motor shaft

and opposite side of stub shaft. See Figure 2.

E.) Install pin




Figure 1




Figure 2

B.) Reassembly:

CAUTION: The mechanical seal is a precision product and should be handled accordingly. Use care when handling the lapped running surfaces of the mechanical seal to ensure they remain clean and free of chips or scratches.

1. Clean gasket and flange faces, seal seat cavity, and stub shaft.
2. Lubricate the seal seat cavity of the adapter and the rubber cup or O-ring of seal seat with the lubricating fluid that comes with the mechanical seal or repair kit. Press the stationary seat in seal seat cavity of the adapter squarely and evenly using an arbor press (if possible) and the cardboard disc supplied with the seal. Be certain that the lapped face (shiny side) is facing you.
3. With motor preferably in vertical position, remount the adapter on motor, making sure the stub shaft does not dislocate or chip the stationary seat of the seal.
4. Apply the lubricating fluid that comes with the mechanical seal or repair kit to the stub

shaft and the rubber bellows of the rotary seal. Slide the seal head on the stub; press the rubber drive band on the rotary head until the lapped face on the head seats firmly against the lapped face of the stationary seat. Do not chip or scratch faces during installation. Take extra care to make sure the lapped faces are clean. Install seal spring on seal head and retainer on spring.

5. Place key in key seat. Line up keyway in impeller with key on stub shaft, and slide impeller on stub shaft. Be certain that the key is positioned in the keyway of the stub and impeller. Slightly compress seal spring with impeller and hold impeller while installing impeller retaining assembly in stub shaft.
6. Insert a screwdriver in a waterway passage of the impeller holding it against rotation and tighten the retaining assembly as discussed in paragraph 7 of disassembly instructions for JM shaft. The impeller will compress the seal spring to the proper length assuring the correct pressure on the lapped surfaces.
7. Remove any burrs caused by screwdriver on the vane of impeller in waterway passage.
8. Slide motor and rotating element in casing. Be sure that any damaged O-ring or gasket is replaced.
9. Tighten casing bolts alternately and evenly.
10. Replace hold-down bolts.
11. Check for free rotation after assembly is completed.
12. Seal all drain openings using pipe sealant on threads.
13. Reprime before starting. Do not start until pump is completely filled with water.

The approved lubricating fluid for seal installation is included with the mechanical seal or repair kit. **DO NOT USE OTHER LUBRICATING LIQUIDS!**

WE RECOMMEND STOCKING A SPARE MECHANICAL SEAL OR REPAIR KIT TO ELIMINATE DOWN TIME.

PRESSURE AND TEMPERATURE LIMITATION STANDARD FITTED PUMPS

PUMP NO.	PRESSURE		TEMPERATURE	
	STANDARD	OPTIONAL	STANDARD	OPTIONAL
69	75 PSI	N/A	220°F	275°F
51, 61, 74	75 PSI	150 PSI	220°F	275°F
77, 82	75 PSI	N/A	220°F	275°F
11, 12, 13, 16, 27, 60, 125, 126	75 PSI	150 PSI	220°F	275°F
62	165 PSI	165 PSI	220°F	275°F
ALL OTHERS	175 PSI	175 PSI	220°F	275°F
N/A-NOT AVAILABLE				

CAUTION

DO NOT ALLOW EITHER THE DISCHARGE PRESSURE OR THE TEMPERATURE OF THE LIQUID TO EXCEED THE LIMITATIONS LISTED ABOVE.